

NSL Dobot — hardware checklist

Responsible: Yixuan Zheng **Event:** ____ **Date:** ____

Tick **Out** when it goes into the box, **Back** when it comes home. Anything left blank in the Back column is still at the venue.

Robot

OUT	BACK	ITEM	QTY	NOTES
☐	☐	Dobot Magician E6 arm	1	In packing posture , in original box and foam
☐	☐	Robot power cable / charger	1	
☐	☐	Emergency-stop switch and cable	1	The arm cannot be enabled without it. Check it is not left plugged into the bench
☐	☐	Ethernet cable, robot LAN1 → laptop	1	
☐	☐	Spare Ethernet cable	1	
☐	☐	USB-C/USB-A → Ethernet adapter	1	Only if a laptop has no Ethernet port
☐	☐	Screws for bolting the base down	set	M6. Count them out and back
☐	☐	Screwdrivers / Allen keys	set	To match the base and flange screws
☐	☐	Bench clamps	2	Backup if the venue table cannot take screws

Ultrasound

OUT	BACK	ITEM	QTY	NOTES
☐	☐	Ballater ultrasound probes	2	Charged the night before
☐	☐	Probe chargers	2	
☐	☐	iPad	1	Charged; ultrasound app installed and signed in
☐	☐	iPad charger and cable	1	
☐	☐	3D-printed probe holders	all	Plus a spare if one exists — they crack
☐	☐	Leg phantom	1	
☐	☐	Ultrasound gel	1	Check it is not nearly empty
☐	☐	Paper towels / wipes	1 pack	For gel on the probe, phantom and hands
☐	☐	Cable ties / Velcro straps	10	Strain-relieve the probe cable to the forearm

Computers and controllers

OUT	BACK	ITEM	QTY	NOTES
☐	☐	Yixuan's Dell laptop (sie182)	1	Runs the teleop. Ubuntu, ROS 2 Humble
☐	☐	Dell charger	1	
☐	☐	Lenovo student laptop 1	1	Windows, DobotStudio Pro — needed to unpack and pack the arm
☐	☐	Lenovo charger	1	
☐	☐	PS5 DualSense controllers	2	Charged
☐	☐	USB-C cables for the controllers	2	Data-capable, not charge-only

Power and stand

OUT	BACK	ITEM	QTY	NOTES
☐	☐	Extension lead / power strip	2	Robot, two laptops, iPad, chargers: at least 6 sockets
☐	☐	Plug adapters	as needed	If the venue is abroad
☐	☐	Tape / barrier for the keep-out zone	1	Mark the arm's 450 mm reach on the table
☐	☐	"Robot in operation" sign	1	

Documents

OUT	BACK	ITEM	QTY	NOTES
☐	☐	Quick guide, printed	2	<code>docs/E6-Quick-Guide.pdf</code> — one for the operator, one spare
☐	☐	Full manual, printed	1	<code>docs/E6-Exhibition-Manual.pdf</code>
☐	☐	This checklist	1	

The night before

DONE	CHECK
☐	Everything above charged: probes, iPad, both laptops, both controllers
☐	Dell laptop: <code>nmcli con up dobot-e6</code> profile still present, repo up to date
☐	Lenovo laptop: DobotStudio Pro opens and connects
☐	Probe holder fits the probe and the flange
☐	Probe assembly weighed — under 750 g

At the venue, before visitors

DONE	CHECK
☐	Arm bolted down, e-stop within the operator's reach
☐	Arm unfolded with DobotStudio Pro — manual §3
☐	Program running, LED flashing green slowly — manual §4
☐	Controller drives all six directions; homing key works
☐	Keep-out zone marked

Packing up

DONE	CHECK
☐	Arm folded into packing posture with DobotStudio Pro before power-off
☐	Every Back box above ticked — especially e-stop, screws and chargers
☐	Gel wiped off probes and phantom before they go in the bag